



Removal Tool

Part No: PLRT

Need Technical Support?

Call:

732-249-8567

Or send an email:

info@eveningstarlighting.com

To remove a Lamp Module: (Example shown in decking)

1. Using the Compressed Air Kit (Part No: PLACB) remove any sand or organic debris around the lamp.
2. Turn the knob counter-clockwise until approximately one Inch of threads are visible.
3. Align the tool vertically over the Lamp Module, and press it down firmly- so it fits snug onto the lamp.
4. Twist the tool 1/4 turn (90°) counter-clockwise, and pull the tool straight up. NOTE: The tool utilizes a wedge fit, so more downward pressure may be required. Do not force or turn the tool more than 1/4 turn or the locking tabs may bend.
5. Clean the mounting surface of all debris. Eject the lamp from the tool by turning the knob clockwise.
6. Turn the knob counter-clockwise until approximately one Inch of threads are visible. Press a new Lamp Module into the tool firmly, with the socket side out.
7. Remove the protective tape on the Module, exposing the socket and anti-corrosive compound. NOTE: Do not wipe off. Inspect the plug and clean of any debris. Press the plug into the socket and insure the anti-corrosive compound covers the boot.
8. Carefully feed the Wire Harness back into the base. Align the locking ears on the Lamp Module with the top of the base. Twist the tool 1/4 turn (90°) clockwise, locking it in place. NOTE: Do not use excessive force or rotate more than 1/4 turn (90°) or the locking tabs may bend.
9. Turn the knob clockwise while holding the tool from turning. The tool will release.

